

HMC S3 Series User Manual



Thank you very much for purchasing our controllers.

Please read this instruction manual carefully before installing, wiring, using, maintaining, and inspecting the product.

Please keep this manual in a safe place and deliver it to the end user.

Statement

The contents of this user manual are subject to change without prior notice.

If you find any suspicion, error, or omission in the content of this user manual, please contact us to change it.

If there are any wrong or missing pages in this user manual, we will replace them for you.

HMC-S3 Series Controller User's Manual

Publisher : Guangzhou Aucotech Automation Technology Limited

Headquarter: Hongshi Business Building, SCI-TECH Industry Park, Baiyun District,
Guangzhou city, PRC

Website: www.aucotech.com.cn

Telephone : +86 020 8489 8493

Change Log

Revision	Description	Originator	Date
V1.0	New Release	czm	2022-08
V1.1	New HMC series controller related manual information sheet	czm	2022-09
V1.2	New Product System Composition	czm	2022-09
V1.3	Change image size	czm	2022-10
V1.4	Add terminal cover schematic, change the definition of communication interface	czm	2022-10
V1.5	Change data storage space value, replace HMC-S3-22N00 external dimensional drawing, change product nameplate description	czm	2022-10
V1.6	Change the model's name and naming rules	czm	2023-02
V1.7	Change the font of the entire manual	czm	2023-03

HMC Series Controller Related Manuals

The following table shows the information, please select the manual according to your needs

Number	Manual Name	Description
1	HMC Series Controller and IO Unit Selection Manual	About the basic functions of controller products.
2	HMC Series Controller Software Getting Started Manual	Software acquisition, installation, getting started tutorial.
3	HMC S3 Series Controller User's Manual (This book)	Explanation on the basic use of S3 series controllers, etc.
4	HMC G300 Series Controller User Manual	About the basic use and functions of the G300 series controllers and other operating instructions.
5	HMC series controller programming basic instruction manual	Understanding of the concept and function of basic controller programming instructions.
6	HMC series controller motion control command manual	Understanding of basic concepts and functions of motion control commands.

*Note: All the above information can be found on the official website: <http://www.auctech.com.cn/>下载.

Table of Contents

- Section 1 Preface 2
- Section 2 Safety Precautions 3
- Section 3 Product Information 7
 - 3.1 Product System Composition 7
 - 3.1.1 HMC-S3-22N00 Function Introduction 8
 - 3.1.2 Local Expansion Unit 9
 - 3.1.3 Remote expansion unit 11
 - 3.2 Naming Rules 12
 - 3.3 Product nameplate description 12
 - 3.4 Specification parameters 13
 - 3.5 Product Structure 14
 - 3.6 Interface Introduction and Definition 14
 - 3.6.1 Interface Introduction 14
 - 3.6.2 Interface Definition 15
 - 3.6.3 Interface Function Introduction 16
 - 3.7 Digital tube indication definition 18
 - 3.8 Local IO terminal definition and wiring 19
 - 3.8.1 Local IO Interface Definition 19
 - 3.8.2 Wiring Diagram 20
 - 3.8.3 Input IO wiring diagram 20
- Section 4 Unit Connection 22
 - 4.1 Power, controller, and local I/O expansion unit connections 22
 - 4.2 Guide rail installation 22
- Section 5 Communication connection 23
 - 5.1 EtherCAT/ModbusTCP bus connection 23
 - 5.2 RS485 communication connection 23
 - 5.3 Monitoring connection via Ethernet 23
- Section 6 Web operation 24
- Section 7 Programming Examples 25
 - 7.1 Preparation before programming 25
 - 7.2 Communication and Configuration 25
 - 7.2.1 Installation description file 25
 - 7.2.2 New project and configuration 26

Section 1 Preface

Thank you for purchasing and using the HMC-S3-22N00 series industrial motion control PLC that developed and produced by Guangzhou Aucotech Automation Technology Limited.




HMC-S3-22N00 controller complies with IEC61131-3 programming specification and supports 6 programming languages of PLCopen standard. Internal integration of USB, RS485, Ethernet, CAN, and other common industrial control interfaces. HMC-S3-22N00 unit supports EtherCAT, MODBUS-TCP, CANopen, RS485, etc. for remote rack expansion and more I/O points.



This manual mainly describes the specifications, parameters, and usage of this product, etc. Please read this manual carefully before use for safer use of this product.

Section 2 Safety Precautions




■ Safety instructions




- Please read and follow these safety precautions when installing, operating, or maintaining the product.
- For personal and equipment safety, please follow all safety precautions described in the markings and manuals on the product when installing, operating, and maintaining the product.
- The "Caution", "Warning" and "Danger" items in the manual do not represent all safety precautions to be observed, but only in addition to all other safety precautions.
- This product should be used in an environment that meets design specifications, otherwise it may cause a malfunction due to failure to comply with the relevant safety precautions.
- The product quality warranty does not cover abnormal function or damage to parts caused by the regulations.
- We will not bear any legal responsibility for personal safety accidents and property damage caused by illegal operation of the product.

Security Level Definition	
 Danger	Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. Additionally, there maybe severe property damage.
 Caution	If not used in accordance with the regulations, may cause fires, serious personal injury, or even death!
 Warning	Failure to use in accordance with the regulations may result in moderate personal injury or minor injury, as well as the occurrence of equipment damage!

When products arrive and are stored	
 Warning	<ul style="list-style-type: none"> ● If the product and product accessories are damaged when opening the box, please do not install them and contact our company or your supplier immediately. ● Check carefully whether the arriving product and the ordered product model match, and whether the product and product accessories are included.
 Caution	<ul style="list-style-type: none"> ● Do not stack multiple of this product on top of each other as this may cause injury or malfunction. ● Do not store in places exposed to direct sunlight, places where the ambient temperature exceeds the temperature conditions for storage, places where the relative humidity exceeds the humidity condition for storage, places where there is a large temperature difference, places where there is high condensation, places near corrosive gases, places where there are flammable gases, places where there is a large amount of dust, dirt, salt or metal dust, places where water, oil or medicine drip, places where vibration or shock can affect the main body of product; otherwise it can lead to fire, Electric shock or machine damage.




	<ul style="list-style-type: none"> Do not hold the cable or motor shaft for weight holding, as this may result in injury or malfunction.
--	---

When designing the system	
 Danger	<ul style="list-style-type: none"> If the rated load of current is exceeded or the load is short-circuited for a long period of time resulting in over-current, the product may start smoking or catch fire. Safety devices such as fuses, or circuit breakers should be set externally.
 Warning	<ul style="list-style-type: none"> Be sure to design safety circuits to ensure that the product system will still work safely if the external power supply is lost, or the product fails. For safe operation of the equipment, please design external protection circuits and safety mechanisms for output signals related to major accidents.
 Caution	<ul style="list-style-type: none"> Be sure to install emergency brake circuits, protection circuits, interlock circuits for forward and reverse operation, and position upper and lower limit interlock switches to prevent damage to the machine in the external circuit of the product. The product may shut down all outputs after detecting abnormalities in its own system; when part of the controller circuit fails, it may cause its output to be uncontrolled. To ensure normal operation, a suitable external control circuit needs to be designed. If the output unit such as relay or transistor of the product is damaged, the output will not be controlled to the ON or OFF state. The product is designed to be used in indoor, overvoltage class II electrical environments, and its power system level should have lightning protection devices to ensure that lightning overvoltage is not applied to the product's power input or signal input, control output and other ports to avoid damage to equipment.



When the product is installed	
 Danger	<ul style="list-style-type: none"> Only maintenance professionals with adequate electrical knowledge and training related to electrical equipment should install this product. For the product with open equipment, please install in the control cabinet with door lock (product cabinet shell protection > IP20), only operators with sufficient electrical knowledge and training related to electrical equipment can open the product cabinet.
 Warning	<ul style="list-style-type: none"> When disassembling the product, the external power supply used for the system must be completely disconnected before performing the operation. Failure to disconnect all power supplies may result in electric shock or product failure and malfunction. While disassembling the product, the power and the power indicator must be turned off for at least 5 minutes, before disassembling the driver. Otherwise, the residual voltage may cause electric shock. Do not use the product in the following places: places with dust, oil fumes, conductive dust, corrosive gases, combustible gases; places exposed to high temperature, condensation, wind, and rain; places with vibration and shock. Electric shock, fire, and misuse can also cause damage and deterioration of the product!
 Caution	<ul style="list-style-type: none"> Avoid metal shavings and wire tips falling into the ventilation holes of the product during installation, this may cause fire, malfunction, and misoperation.

	<ul style="list-style-type: none"> • After installation, ensure that there is no foreign matter on the ventilation surfaces, otherwise it may lead to poor heat dissipation and cause fire, malfunction and misoperation. • When installing, make a tight connection to the respective connector and lock the product connection hook firmly. If the products are not installed properly, it may lead to misoperation, malfunction and dislodgement.
--	--




When wiring products

 Danger	<ul style="list-style-type: none"> • Only maintenance professionals with adequate electrical knowledge and training related to electrical equipment should perform the wiring of this product.
 Warning	<ul style="list-style-type: none"> • During wiring operations, the external supply power used by the system must be completely disconnected before operation. Failure to disconnect all of them may result in electric shock or equipment malfunction or misoperation. • When powering up and running after the wiring operation, the terminal cover that comes with the product must be installed. Failure to install the terminal cover may result in electric shock. • Check the type of interface to be connected before connecting the cable correctly. If the wrong interface is connected or the wiring is incorrect, it may cause the product or external equipment to malfunction. • The cable terminals should be well insulated to ensure that the insulation distance between the cables is not reduced after the cables are installed to the terminal block. Otherwise, it will lead to electric shock or equipment damage. • Avoid metal shavings and wire tips falling into the ventilation holes of the controller when wiring, which may cause fire, malfunction, and misoperation! • The bolts on the terminal blocks should be tightened within the specified torque range. Untightened terminal bolts may result in short circuit, fire, or malfunction. Over-tightening the bolts may damage the bolts and the product, resulting in dislodgement, short circuit, fire, or false operation.
 Caution	<ul style="list-style-type: none"> • The specification and installation method of the external wiring of the equipment should meet the requirements of local power distribution regulations. • To ensure the safety of the equipment and the operator, the equipment needs to be reliably grounded using cables of sufficient wire size. • For connections using connectors and external devices, press fit, crimp, or properly solder using the tool specified by the manufacturer. A poor connection may result in a short circuit, fire, or malfunction. • If the product is labeled to prevent foreign objects from entering the product during wiring, such as the wiring head. Do not remove this label during wiring operations. Before starting system operation, be sure to remove the label to facilitate heat dissipation. • Please do not bundle the control and communication cables with the main circuit or power supply cables, etc. The alignment should be more than 100mm apart, otherwise the noise may lead to misoperation. • For applications with serious interference, please use shielded cables for input or output of high frequency signals to improve the system's anti-interference capability.


Before powering on the product

 Danger	<ul style="list-style-type: none"> • Before powering on, please make sure the product is well installed, wired firmly and the motor unit is allowed to restart. • Before powering on, please confirm that the power supply meets the product requirements to avoid causing damage to the product or starting a fire. • It is strictly forbidden to open the product cabinet door or product protective cover, touch any terminals of the product, disassemble any device or parts of the product in the energized state, otherwise there is a risk of electric shock. • Make sure that no one is around the product, the motor, or the machinery before powering it on, as this may result in injury or death!
 Warning	<ul style="list-style-type: none"> • After the wiring operation and parameter setting are completed, please conduct a test run of the machine to confirm that it can operate safely, otherwise it may lead to injury or equipment damage! • Before powering on, please make sure that the rated voltage of the product is the same as the power supply voltage. If the power supply voltage is used incorrectly, there is a risk of fire!

When operating and maintaining

 Danger	<ul style="list-style-type: none"> • Only maintenance professionals with adequate electrical knowledge and training on electrical equipment can perform the operation and maintenance of the products. • Do not touch the terminals when the power is on, as this may cause electric shock or malfunction. • When the motor or equipment is running, please never touch its rotating parts, otherwise it may lead to serious personal safety accidents.
 Warning	<ul style="list-style-type: none"> • When cleaning the product or retightening the bolts on the terminal block or the connector mounting bolts, the external supply power used by the system must be completely disconnected. Failure to do so may result in electric shock. • When disassembling the product or connecting or removing the communication cable, the external supply power used by the system must be completely disconnected first. Failure to disconnect all of them may result in electric shock or false operation. • While dissembling the product, the power and the power indicator must be turned off for at least 5 minutes, before disassembling the driver. Otherwise, the residual voltage may cause electric shock.
 Caution	<ul style="list-style-type: none"> • For online modification, forced output, RUN, STOP, etc., you must read the user's manual and confirm its safety before performing the relevant operations. • Be sure to disconnect the power before loading and unloading expansion cards, modules, and other components!

When the product is scrapped


 Caution	<ul style="list-style-type: none"> • Please dispose of them as industrial waste; when disposing of batteries, do so separately according to the ordinances established by each region to avoid property damage or human injury! • End-of-life products should be treated and recycled in accordance with industrial waste treatment standards to avoid polluting the environment.
---	---

Section 3 Product Information

HMC-S3 series is a medium-sized programmable controller with modular structure design. Each rack supports local expansion of 16 expansion units and remote expansion of the rack through various industrial fieldbuses such as EtherCAT and CANopen. The local expansion units can be expanded through internal bus protocols, and support digital input/output units, analog input/output units, temperature units and remote function units. Among them, the analog input/output unit adopts 16-bit resolution conversion chip to further improve the signal conversion accuracy. The motion control function is realized through EtherCAT bus, the 2ms execution cycle supports 16-axis motion control with single-axis acceleration/deceleration control function electronic gear function and electronic cam function.

3.1 Product System Composition

- The following three accessories are required to form a properly functioning motion control system:
 - 1) Power supply part: HMC-S3-22N00 power supply requires the use of internal mutually isolated dual 24V power supply or the use of two independent 24V power supplies and requires the power supply current to be greater than 2.7A/way.
 - 2) The HMC-S3-22N00 is the core component of the system and is the management and control center of the whole system. See subsection 3.1.1 for a description of the relevant functions.



HMC-S3-22N00 diagram TK6-END terminal cover diagram

Note: This model controller 1:1 is equipped with terminal cover plate (TK6-END), please keep it properly. When there is only the controller at the application site, the terminal cover plate should be installed on the right side of the controller. If there is an expansion unit installed on the right side of the controller, the terminal cover plate should be installed on the right side of the last expansion unit, otherwise the expansion IO cannot be used normally.

- 3) Rail: HMC-S3 series products are designed with modular structure, the controller and other expansion units are installed on the rail and then fixed to the corresponding fixed plane.

Note: Please use DIN35 standard guide, complete shape, no insulating paint, good conductivity, this accessory can be purchased by the user. (Please refer to subsection 4.2 for specific installation)

- 4) Based on the above products, users can continue to select the appropriate type of expansion units according to their needs to build a local control system or a remote-control system that meets their requirements. Please refer to section 3.1.2 for local expansion units and section 3.1.3 for remote expansion units. For the specific wiring of each unit before use, please refer to the user manual of the relevant product.

3.1.1 HMC-S3-22N00 Function Introduction

Controller Model	HMC-S3-22N00	
Number of local expansion units	16	
Program storage space	4GB	
Data storage space	2MB+512KB (power-down hold)	
Number of motion control axes	16 axes (2ms execution cycle)	
Communication	RS485	√
	LAN	√
	EtherCAT	√
	CANopen	√
	Modbus TCP	√


● **Description of each communication port of the controller**

Controller communication port	Communication protocols	Connections	Application Notes	Matching Unit
LAN1/LAN2/ECAT	Ethernet/EtherCAT	CAT5E Cable	2-way independent 10/100 (LAN2/ECAT) 1 100M/1000Mbps (LAN1) adaptive Ethernet interface: LAN1:192.168.1.91, LAN2:192.168.2.92. Supports Ethernet (Modbus TCP) protocol. Support EtherCAT protocol.	TM6-ECT-32DM-N TM6-ECT-4HC TM6-ECT-2PM

DB9	MODBUS-RTU/CANopen	DB9	RS485 interface, support Modbus protocol CAN interface, support CANopen protocol Standard 3-channel RS485, 1-way CAN;	—
USB	-	Mini USB	On-site maintenance and debugging (other functions can be customized according to user requirements, such as USB expansion	—

3.1.2 Local Expansion Unit

- Dimensional drawing



● Function Introduction

Model	Type	Product description
TK6-16DI*	Digital Unit	TK6 series; 16-channel digital input unit.
TK6-8DO-R*		TK6 series; 8-channel digital output unit, relay type.
TK6-16DO-N*		TK6 series; 16-channel digital output unit, NPN transistor type.
TK6-16DO-P		TK6 series; 16-channel digital output unit, PNP transistor type.
TK6-16DM-N*		TK6 series; 8-way DI+8 way DO unit, NPN transistor type.
TK6-32DI		TK6 series; 32-way digital input unit.
TK6-16DO-R		TK6 series; 16-channel digital output unit; relay type.
TK6-32DO-N		TK6 series; 32-channel digital output unit; NPN transistor type.
TK6-32DO-P		TK6 series; 32-channel digital output unit; PNP transistor type.
TK6-32DM-N		TK6 series; 16-way DI+16 way DO unit; NPN transistor type.
TK6-8HAI-C	Analog Unit	TK6 series; 8-way analog high precision input unit; 16-bit high precision; current input.
TK6-8HAI-V		TK6 series; 8-way analog high precision input unit; 16-bit high precision; voltage input.
TK6-8HAO-V		TK6 series; 8-way analog high-precision output unit; 16-bit precision; voltage input
TK6-4HAI-C		TK6 series; 4-way analog high precision input unit; 16-bit high precision; current input.
TK6-4HAO-V		TK6 series; 4-way analog high-precision output unit; 16-bit precision; voltage input
TK6-8HAI-B		TK6 series; 8-way analog high-precision input unit; 16-bit precision; voltage or current, $\pm 10V$ or $0\sim 20mA$;
TK6-4HAO-B*		TK6 series; 4-way analog high-precision output unit; 16-bit precision; voltage or current, $\pm 10V$ or $0\sim 20mA$;
TK6-8HAO-B		TK6 series; 8-way analog high-precision output unit; 16-bit precision; voltage or current, $\pm 10V$ or $0\sim 20mA$;
TK6-8HAO-C		TK6 series; 8-channel analog high-precision output unit; 16-bit precision; current input; $4\sim 20mA/0\sim 20mA$;
TK6-4HAI-B*		TK6 series; 4-way analog high-precision input unit; 16-bit precision; voltage or current, $4\sim 20mA/0\sim 20mA\pm 10VDC$;
TK6-4PT	Temperature measurement unit	TK6 series; 4-way analog RTD unit; 24-bit resolution; PT100, PT1000, etc;
TK6-8PT*		TK6 series; 8-way analog RTD unit; 24-bit resolution; PT100, PT1000, etc;
TK6-4JK		TK6 series; 4-way analog thermocouple unit; 24-bit resolution; J, K, etc;


Note: *For products under planning, please contact AUCTECH for details.

● Software Function Description

Number	Function	Description
1	Power-down hold function	Power-down hold function without calling the power-down hold library.
2	System time function	If there is no battery in the controller, the system time restores the initial time after power failure and restart.

3.1.3 Remote expansion unit

- External dimensional drawing




- Function Introduction

Model	Type	Product description
TM6-ECT-32DM-N	Coupler Unit	TM6 series; 32 digital input/output unit; EtherCAT bus; 2 RJ45 communication ports; expandable by 32 units; 24VDC power supply; 16 digital inputs (source/drain inputs), 16 digital outputs (NPN transistors)
TM6-ECT-2PM*		TM6 series; EtherCAT bus; 24VDC power supply; 2-axis pulse output, single-ended (NPN output up to 500KHZ)
TM6-ECT-4HC		TM6 series; EtherCAT bus; 2 RJ45 communication ports; 24VDC power supply, rotary encoder (AB phase), pulse + direction (single-ended, max. 200KHZ)
TM6-ECT-4PM		TM6 series; EtherCAT bus; 2 RJ45 communication ports; 24VDC power supply; 4-axis pulse output, single-ended (NPN output up to 500KHZ) or differential (output up to 500KHZ)
TM6-ECT-3COM*		TM6 series; EtherCAT bus; 3 RJ45 communication ports; 24VDC power supply; 3 RS485 interfaces, support Modbus RTU and free port protocol


Note: *For products under planning, please contact AUCTECH for details.

3.2 Naming Rules



Note: The naming rules are only for model number analysis, and cannot be

3.3 Product nameplate description



3.4 Specification parameters

Model		HMC-S3-22N00		
Processor main frequency		4 cores*1.2GHZ		
Memory	For programs	4GByte		
	For data	2MB+512K (2MB power down hold)		
	Expandable memory	32G, pluggable SD card		
Storage		Nand Flash permanent storage, no battery backup required		
Programming		IEC61131-3 programming languages (LD, FBD, IL, ST, SFC, CFC)		
Program execution		Compile and execute		
Instruction processing		4ns/basic instruction		
Maximum capacity of IO points	Digital channels		131072	
	Analog channels		32768	
Communication Interface	Serial Interface	RS485	3-way RS485, 9-pins D-type connector (hole type), free port protocol support, Modbus RTU/ASCII master/slave protocol	
	Network Interface	CAN	1 way, 9-pins D-type connector (hole type), CANopen protocol support	
		Modbus TCP/EtherCAT	1 CAN independent 10/100M, 1 100M/1000Mbps adaptive Ethernet interface, configurable as Modbus TCP/EtherCAT according to configuration	
Local IO parameters	Number of channels		16-channels input 16-channels output	
	Input	ON Current	5mA	
		Input Impedance	3.3kΩ	
		ON state voltage	13-30V	
	Output	Maximum load current	0.5A/channel	
		Voltage output range	12-32V	
EtherCAT Parameters	Support Services		CoE (PDO, SDO)	
	Camshaft (contains both real and imaginary shafts)	Execution cycle (ms)	Axes (pcs)	Description
		2	16	
	Synchronization method		Servo with DC-distributed clock, IO with input-output synchronization	
	Physical Layer		100BASE-TX	
	Speed		100Mbit/s(100BASE-TX)	
	Duplex method		Full Duplex	
	Number of slave stations		Up to 125 units	
EtherCAT Frame Length		44 bytes~1498 bytes		

Model	HMC-S3-22N00	
	Process Data	Single Ethernet frame up to 1486 bytes
	Transmission distance	Less than 100M between two nodes
Parameter Configuration	Web-based configuration of network information	
Supply voltage	24VDC (-15% to 20%) for both groups	
Current consumption	500mA@24VDC	

3.5 Product Structure




Figure 1 HMC-S3-22N00 external dimensional drawing

3.6 Interface Introduction and Definition

3.6.1 Interface Introduction





Figure 1 HMC-S3-22N00 module interface schematic



(14) Power supply interface (12) Backplane bus interface


Figure 2 HMC-S3-22N00 module interface schematic

3.6.2 Interface Definition

Number	Interface Name	Function Definition
6~8	Ethernet/EtherCAT interfaces (LAN1, LAN2, ECAT)	2 independent 10/100 (LAN2/ECAT). 1 x 100M/1000Mbps (LAN1) adaptive Ethernet interface. LAN1:192.168.1.92, LAN2:192.168.2.92. Supports Ethernet (Modbus TCP) protocol. Support EtherCAT protocol.
10	DB9-RS485, CAN	RS485 interface, support Modbus protocol CAN interface, support CANopen protocol 3-channel RS485, 1-channel CAN as standard;
1	USB interface	On-site maintenance and debugging (other functions can be customized according to user requirements, such as USB expansion NIC, USB Wi-Fi module, USB authorization module, etc.)
3	Dipswitch	RUN/STOP switch
5	SD card slot	Expandable up to 32G SD card, SD card for firmware

		update, application, and data storage
4	MFK Button	Multi-functional keys
2	Digital tube	Display of operating status and fault information (refer to Table 6 for details)
12	Backplane bus interface	Expandable with up to 16 IO modules when adapted to TK6 series IO
11	Local IO terminal block	Local IO input and output wiring (refer to Table 7 for detailed terminal definitions)
14	Power supply interface	Dual 24VDC power inputs

● Description of the power supply interface

Number	Name	Type	Function	Remarks
14	GND	Input	DC input ground	Body output IO and expansion module power supply
	+24V	Input	24V DC input	
		-	Functional ground (connection system housing)	-
	GND	Input	DC input ground	Controller body power supply
	+24V	Input	24V DC input	


3.6.3 Interface Function Introduction

● RUN/STOP switch

Run or stop runtime by switch to facilitate the operation of individual IO points on site via web page to judge whether IO points are normal or not.

● MFK Button

Restore factory settings (IP reset, clear applications, user configuration, etc.)



5、 Power off and reboot the system

After restoring the factory settings, the network information is: LAN1: IP 192.168.1.92, mask 255.255.255.0 gateway 192.168.1.1, LAN2: IP 192.168.2.92, mask 255.255.255.0 gateway 192.168.2.1, ECAT: no IP, the system will automatically reboot).

- LAN1, LAN2, ECAT function description

It can be configured as Ethernet or EtherCAT according to the configuration; in Ethernet mode, it supports Modbus TCP/IP master/slave protocol for program download and debugging, extending remote racks, and connecting to other industrial configuration systems, etc.; in EtherCAT mode, it is used to extend racks or remote EtherCAT IO modules and third-party EtherCAT operating mode is used to extend racks or remote EtherCAT IO modules and third-party EtherCAT slave devices.

- LED indicator function description

Indicator light	Function	Status	Meaning
PWR	Power supply indication	Always bright	Normal power supply
		extinguish	No power supply
RUN	Program operation instructions	Always bright	The program is running properly
		extinguish	Program stops running
ERR	Error indication	Always bright	Error
		extinguish	Normal
0...F	The previous group 0...F identifies 0...15DI inputs; the next group 0...F identifies 0...15DO outputs;	Always bright	Channel has input/output
		extinguish	Channel has not input/output

- (RS485, CAN) port definition description

DB9 adopts standard DB9 female connector, supports 1 CAN interface and 3 RS485 interfaces, refer to Figure 4 for interface pin definition.




Figure 3 DB9 Port Definition

Name	Corresponding CPU hardware ports	Name	Corresponding CPU hardware ports
H0, L0	CAN1	A1, B1	Serial port 1
B3, A3	Serial port 3	A2, B2	Serial port 2

3.7 Digital tube indication definition

Digital tube display	Meaning	Countermeasures
01 80	Rack error, 01 means local rack error, extended rack by configuration and so on	Find the corresponding error rack, you can check the subsequent error code to find the error type of the rack. For specific errors, further check the information on the digital tube of the error rack
81	Initialization rack error	Check whether the hardware connection of the rack is normal, whether the relevant configuration of the rack is correct, specific errors need to further check the information on the digital tube of the wrong rack
82	Rack internal error	Check whether the rack is working properly, specific errors need to further check the information on the digital tube of the error rack
83	Configuration mismatch	Check that the configuration of the rack and the modules on the rack are consistent with the background configuration
84	Setting module parameter error	Check whether the rack is working properly, confirm whether the module connection is normal and whether the module is damaged
85	Error getting hardware configuration information	Check whether the rack is working properly and whether the module is broken
86	Update module output data error	Check whether the rack is working properly and whether the module is broken

87	Update module input data error	Check whether the rack is working properly and whether the module is connected properly
88	Sending rack command data error	Check if the rack is working properly and check if the rack configuration is correct
89	Remote rack disconnection	Check if the rack is working properly and check if the network connection is normal
8a	Remote rack with IP duplication	Check whether the rack configuration is correct, you can further view the information on the error rack digital tube
C1	EtherCAT Slave Error	Check whether the hardware link of the slave is properly connected, and after locking the wrong slave, you can check the digital tube error message on the slave to analyze the specific error
C2	EtherCAT slave stops running	Check whether the hardware link of the slave is properly connected, and after locking the wrong slave, you can check the digital tube error message on the slave to analyze the specific error
3C	EtherCAT slaves have valid diagnostic information	Check whether the hardware link of the slave is properly connected, and after locking the wrong slave, you can check the digital tube error message
5A	PLC programs stop	PLC program is in stop state, pending start
5B	PLC program exception	Check the program for exceptions such as divide by zero or null pointer

Note: The word code displayed by the digital tube indicates the hexadecimal error code.


3.8 Local IO terminal definition and wiring

3.8.1 Local IO Interface Definition


Terminal number	Function	Terminal number	Function	Remarks
I0	Input (IN0)	I1	Input (IN1)	
I2	Input (IN2)	I3	Input (IN3)	
I4	Input (IN4)	I5	Input (IN5)	
I6	Input (IN6)	I7	Input (IN7)	
I8	Input (IN8)	I9	Input (IN9)	
IA	Input (IN10)	IB	Input (IN11)	
IC	Input (IN12)	ID	Input (IN13)	
IE	Input (IN14)	IF	Input (IN15)	
C0	Input Common	C0	Input Common	
Q0	0V output (OUT0)	Q1	0V output (OUT1)	
Q2	0V output (OUT2)	Q3	0V output (OUT3)	
Q4	0V output (OUT4)	Q5	0V output (OUT5)	

Q6	0V output (OUT6)	Q7	0V output (OUT7)	
Q8	0V output (OUT8)	Q9	0V output (OUT9)	
QA	0V output (OUT10)	QB	0V output (OUT11)	
QC	0V output (OUT12)	QD	0V output (OUT13)	
QE	0V output (OUT14)	QF	0V output (OUT15)	
C1	Output common (connected to 0V)	C1	Output common (connected to 0V)	

3.8.2 Wiring Diagram




3.8.3 Input IO wiring diagram



Note: The body IO is NPN drain type output, and the controller field bus power terminal needs to be connected to 24V power supply. Output IO can be set to hold and non-hold switching

- If "Update when stop" is checked, the output behavior is "Keep current value", the output IO signal will remain true when the program stops; the output behavior is "Set all outputs to default ", when the program stops, the output IO signal will be reset back to false.



Section 4 Unit Connection

The S3 series provides a complete range of product units and series, and each unit can be seamlessly connected to each other, simplifying the process of project implementation and use.

4.1 Power, controller, and local I/O expansion unit connections

The HMC-S3-22N00 can be used seamlessly with our TM6/TK6 series products, and the controller, power supply, and units are tightly connected by internal clips.

4.2 Guide rail installation

- 1) Pull all the snaps on the back of all modules in the unit (as shown in Figure 7) all the way down. It should be pulled until it clicks.




Figure 4 Pull down snap

- 2) Hang the fixing claws on the upper side of the unit to the upper side of the rail as shown in the direction of Figure 8 A. Press the unit set firmly until it is completely embedded in the rail as shown in Figure 8 B.




Figure 5 Installation units 1

- 3) Lock the snap of the unit and embed it into the rail. Press upward until it clicks, as in Figure 9. If your fingers cannot reach the snap, you should use a tool such as a screwdriver and remember don't apply too much torque.




Figure 6 Installation units 2

Section 5 Communication connection

5.1 EtherCAT/ModbusTCP bus connection

The HMC-S3-22N00 network interface supports both EtherCAT and ModbusTCP network communication modes. EtherCAT mode supports regular EtherCAT device connection communication. Modbus TCP mode supports Modbus-TCP server/client protocol, generally by calling function blocks to achieve communication. Also, the working mode of the network interface can be configured by configuration programming software. The configuration mode is generally used as a client and the M-zone accesses data, and the former is recommended.

5.2 RS485 communication connection

The RS485 communication interface uses the standard DB9 interface, and the interface is defined in Figure 4, which is connected according to the requirements.

5.3 Monitoring connection via Ethernet

HMC-S3-22N00 integrates MQTT client, MODBUS-TCP Client function to provide data access interface for upper layer communication.

1. Point-to-point connection with PC, HMI, etc. via Ethernet cable
2. Connect to hub or switch through Ethernet cable, and then connect to PC, HMI, and other network devices to realize multi-point connection.





Figure 7 HMC-S3-22N00 connects to other devices through the switch


Section 6 Web operation

Debug the computer and controller LAN1 network port with a network cable connection, open the browser page, enter the network port IP, and port number, the web default login account password for admin and admin, you can enter the web operation interface, as follows

- 1) Web page directly hit the IP: 192.168.1.92:8090; login account password is admin and admin



- 2) Click on the network card to change the IP address



Section 7 Programming Examples

HMC-S3-22N00, two TK6 series IO units programming example, realize controller local IO input and output, control two TK6 series IO units data interaction.

7.1 Preparation before programming


- Software
 - 1) Installation of the programming software CODESYS on a PC that meets the installation environment.
 - 2) Start the CODESYS software and install the device description file and function library.
- Hardware

According to the actual application scenario, the hardware is connected to the controller (HMC-S3-22N00), the CODESYS TK6 series IO modules, etc., and the power is supplied as required. Connect the controller Ethernet interface via network to a PC with CODESYS software installed.


7.2 Communication and Configuration

7.2.1 Installation description file


- 1) Add the Package file of controller HMC-S3-22N00
- 2) Click on "Tools" on the CODESYS software toolbar and select CODESYS Installer.



- 3) Once in the package manager, click Install




4) Select the corresponding Package file to install



7.2.2 New project and configuration


1) New project, select standard project




- 2) Controller device selection, this controller is HMC-S3-22N00




- 3) Scan the device, the controller IP address is 192.168.1.92 or 192.168.1.93 by default, double click to select the controller




4) After successful scanning, the controller and PC communicate on




5) Click Login and Run to view communication status




- 6) Right-click STDIOPBus (STDIOPBus) and click Scan Device



- 7) Scan out the results and copy all devices to the project



- 8) Re-login to check communication status



Reversion: V1.7



AUCTECH AUTOMATION

GUANGZHOU AUCTECH AUTOMATION TECHNOLOGY LIMITED

Hongshi Business Building, SCI-TECH Industry
Park, Baiyun District, Guangzhou city, PRC

Fax	Web	Mail
+86 020 8489 8493	www.auctech.com.cn	info@auctech.com.cn
